

Step 1

Open the light stand by turning the knob at the top of the legs counter-clockwise.



Step 2

Attach the casters to the light stand by inserting a metal shim into each caster and sliding a caster onto the end of each light stand leg. Tighten by turning the knob on the caster.



Step 3

Insert the swivel into the top of the stand and tighten.




Step 4

Insert one half of the boom arm into the pivoting swivel. Tighten with the ratcheting lever on the swivel.



Step 5

Place the silver insert into the open end of the attached boom arm, lining up the hex screw on the insert with the hole in the boom arm. Use the included hex key to tighten the hex screw. This forces the silver insert to expand and tighten against the inside of the boom.



Step 6

Slide the open end of the second half of the boom arm over the silver insert, lining up the hex screw on the silver insert with the hole in the boom arm. This will be a tight fit, so you may need to wiggle the arm to get it aligned.

Once lined up, tighten the hex screw to join the two halves of the boom. Adjust both hex screws as needed to secure the attachment of the arm.



Step 7

Slide the orange counter-weight on to the end and tighten. The weight is heavy, so support it with both hands. Its position can then be adjusted up and down the boom arm as needed.

